

Eye-Sight V5.1.1 upgrade:

- 1) Update the FW version via the IP manager Tool selecting “software upgrade” using the file with “tar” extension.
 - 2) Update the Kernel version via the IP manager Tool selecting “kernel upgrade” using the file with “bin” extension.
- The above two updates will keep all camera settings the same.

Please feel free to contact our technical team with any question, concern or technical feedback.

Best Regards,
Provision-ISR Technical Department.