

Dear customer,

FW v 148_63842

this FW update should be performed locally via USB pen and menu \ or just reboot the recorder.

Provision-ISR Technical Team

1) ABSOLUTE MOVE

Camera control command that positions a PTZ camera to specific coordinates or angles with absolute precision, allowing for accurate and predetermined camera positioning. This command ensures that the camera moves directly to the specified location rather than making relative adjustments.

2) BUG FIXES.

Provision-ISR Technical Team